

MC9190-G

Quick Start Guide


BATTERY INSERTION

<http://www.zebra.com/mc9190g>


See User Guide for more information

POST IN WORK AREA


Front View





Battery Removal




Stylus Removal



SNAP-ON ACCESSORY INSTALLATION



Cable Adapter Module




Data
Power


Magnetic Stripe Reader

CHARGING INSTRUCTIONS


⦿ = LED Indicator Location Slow Flash = Normal Charge Solid Amber = Full Charge Fast Flash = Charging Error



Four Slot Spare Battery Charger



Single Slot Serial/USB Cradle




Four Slot Cradles




Charge-Only Cradle and Ethernet Cradle

OPTIMUM IMAGING AND SCANNING POSITIONS




Laser Scanning



Standard Range Imaging




Long Range Imaging



OPTIMUM UPRIGHT BODY POSTURE



AVOID EXTREME WRIST ANGLES



ALTERNATE LEFT AND RIGHT HANDS
TAKING BREAKS AND TASK ROTATION RECOMMENDED



AVOID EXTREME
WRIST ANGLES




OPTIMUM BODY POSTURE

Low Scanning

Alternate left and right knees



AVOID BENDING



Alternate left and right hands



AVOID REACHING



High Scanning

Use a ladder



Taking breaks and
task rotation recommended



Zebra Technologies Corporation, Lincolnshire, IL USA
Zebra and the Zebra head graphic are registered trademarks of ZIH Corp. The Symbol logo is a registered trademark of Symbol Technologies, Inc., a Zebra Technologies company.
© 2015 Symbol Technologies, Inc.



72-139206-02 Rev. B - April 2015



<http://www.zebra.com/mc9190g>